

# pTrumpet<sup>®</sup> Care Card

pTrumpet is durable, but not indestructible!

Here are a few tips to help you enjoy and care for your new pTrumpet:

- Use a soft cloth and warm soapy water to clean your instrument and be sure to rinse through before use.
- The main, first and third valve tuning slides are all adjustable. When new and from time to time apply a little tuning slide grease to the black moving parts/tuning slide legs.
- Best results are achieved by lightly holding the valve block. Ensure that the valve is completely clean and is free of obstruction - such as excessive valve oil.
- Due to its innovative design, the instrument valves are functional dry and do not require the use of an oil based lubricant for operation.
- You may use regular trumpet valve oil sparingly.
- All the valve pistons are the same.
- To remove the valves gently turn the valve bottom caps anti-clockwise and remove the cap, spring and valve piston.
- To return the valve, place the piston back into the valve block, gently twist to seat into its guide channel and push all the way in. Replace the spring into the bottom valve cap, secure the valve bottom cap by pushing upwards and twisting clockwise.

Please register your pTrumpet using the serial number printed under the main stay for an extended warranty, **free** exclusive coaching videos and downloadable trumpet music at [www.ptrumpet.com/register](http://www.ptrumpet.com/register)

For more detailed instructions about caring for your instrument please visit [www.ptrumpet.com/care](http://www.ptrumpet.com/care)

Above all have **FUN!!!**

[www.ptrumpet.com](http://www.ptrumpet.com)



# pTrumpet<sup>®</sup> Limited Warranty

## Limited Warranty

Warwick Music Ltd warrants to the original owner-user that the pTrumpet product will be free from defects in material or workmanship. This warranty is limited to 30 days from the date of original purchase, whether or not actual use.

## Limitations and Exclusions

Warranty inquiries must be made through an authorized Warwick Music dealer or arranged through Warwick Music Customer Service. Authorized returns must be shipped prepaid.

1. The warranty provided herein shall be void and of no effect in the event that (a) the product has been operated outside its designed output capacity.
2. The warranty provided herein is for replacement only. Warwick Music Ltd shall not be liable for any loss, cost, damage, or expense of any kind arising out of a breach of the warranty. Further, Warwick Music Ltd shall not be liable for any incidental, consequential, exemplary, special, or punitive damages, nor for any loss of revenue, profit or use, arising out of a breach of this warranty or in connection with the sale, maintenance, use, operation or repair of the pTrumpet product. In no event will Warwick Music Ltd be liable for any amount greater than the purchase price of a defective product. The disclaimers of liability included shall remain in effect and shall continue to be enforceable in the event that any remedy herein shall fail of its essential purpose.
3. THIS WARRANTY IS THE SOLE AND EXCLUSIVE WARRANTY FOR THE PTRUMPET, AND IS IN LIEU OF ALL OTHER EXPRESS AND IMPLIED WARRANTIES. WARWICK MUSIC SPECIFICALLY DISCLAIMS ALL OTHER EXPRESS AND IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

No person or entity is authorized to bind Warwick Music to any other warranty, obligation or liability for any pTrumpet product. Installation, operation or use of the Warwick Music Ltd product for which this warranty is issued shall constitute acceptance of the terms hereof.



Effective 27th January 2017